

Contents:

- Elo Pay M100
- 45W Adapter

- US/EU/UK Adapter Plugs
- 1.8m USB-Cable

Caution:

Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

EU Battery Declaration

This symbol on the battery(ies) or on the packaging indicates that the battery(ies) provided with this product should not be treated as household waste. Instead, please separate the battery(ies) from other types of waste and recycle them through your local recycling system to protect the environment and health. The chemical symbol for lead (Pb) is added under this symbol if the battery(ies) contains more than 0.004% lead. Additionally, the chemical symbol for cadmium (Cd) is added under this symbol if the battery(ies) contains more than 0.002% cadmium.



For more detailed information about the recycling of these batteries, please contact your local authority or the shop where you purchased the product or batteries.

Learn more about Elo at [EloTouch.com](https://www.elotouch.com)

America

Tel +1 408 597 8000
EloSales.NA@elotouch.com

Europe (EMEA)

Tel +32 16 930 136
EMEA.sales@elotouch.com

Asia Pacific

Tel +86 (21) 3329 1385
EloAsia@elotouch.com

The information in this document is subject to change without notice. Elo Touch Solutions, Inc. and its Affiliates (collectively "Elo") makes no representations or warranties with respect to the contents herein, and specifically disclaims any implied warranties of merchantability or fitness for a particular purpose. Elo reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Elo to notify any person of such revisions or changes.

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, including, but not limited to, electronic, magnetic, optical, chemical, manual, or otherwise without prior written permission of Elo Touch Solutions, Inc.

Elo and the Elo logo are either trademarks or registered trademarks of Elo Touch Solutions, Inc.

© 2024 Elo Touch Solutions, Inc. All rights reserved.



Quick Installation Guide


Elo Pay M100

Revision A
P/N QIG600285

[www.EloTouch.com](https://www.elotouch.com)

- Ambient Light Sensor
- Function LED
- Power LED

Contactless pay area
(graphic to be image on screen)




I/O Connector
USB-C

Programmable Button
(Defaults as Scan Trigger for Scanner SKUs)

Front Camera


SCR slot



Scanner + MSR

Optional

Rear camera and Flash



Volume
Up/Down Button


Power Button

Programmable Button
(Defaults as Scan Trigger for Scanner SKUs)

SCANNER SKU P/N: E121593, E121973, E121214

NO SCANNER SKU P/N: E121790, E122179, E121405

SCANNER + MSR SKU P/N: E287818, E288007, E287625



Scanner

Optional

Go to www.elotouch.com/support to download user manual.